

2496N

LOCKING CLAMP

001




TABLE OF CONTENTS

002

03: what is a locking clamp?

04: parts list

06: locking clamp diagrams

07: instructions

73: video tutorial

WHAT IS A LOCKING CLAMP?

003

A VEX locking clamp is a **mechanism** designed to **hold game elements** with a grip that makes removing the element from the clamp **extremely difficult**.

The most effective way of constructing this subsystem is with a focus on **levers**, precise **geometry**, and **pneumatics**.

The system uses compressed air to actuate **pivoting** levers, resulting in the final lever **securing** the game element.




DID YOU KNOW?

Many teams have used this subsystem in the '21-'22 Tipping Point season and this year's game: High Stakes!


PARTS LIST

004




2x

1x2x13 Aluminum C-Channel




1x

1x2x10 Aluminum C-Channel




2x

1x2x9 Aluminum C-Channel




1x

1x2x6 Aluminum C-Channel




2x

1x5x5 Aluminum C-Channel




2x

1x1x4 Aluminum Angle




2x

90 Degree Large Flat Gusset




21x

Thin Nylock Nut




6x

Keps Nut




1x

Hex Nut




6x

Flat Bearing



5x

1/2" x 3/8" OD x #8 Nylon Spacer




4x

1/4" x 3/8" OD x #8 Nylon Spacer


PARTS LIST

005




4x

3/8" x 3/8" OD x #8 Nylon Spacer




10x

1/8" x 3/8" OD x #8 Nylon Spacer




10x

1/16" x 3/8" OD x #8 Nylon Spacer




1x

1/32" x 3/8" OD x #8 Nylon Spacer




4x

#8-32 x 1/4" Star Drive Screw




4x

#8-32 x 3/8" Star Drive Screw




4x

#8-32 x 5/8" Star Drive Screw



9x

#8-32 x 1-1/84" Star Drive Screw



1x

Cylinder Mount







1x


75mm Stroke Pneumatic Cylinder

LOCKING CLAMP DIAGRAMS

006




1




1x

1x2x13 Aluminum C-Channel




1x

#8-32 x 1-1/8" Star Drive Screw




2




1x

1x2x1x9 Aluminum C-Channel




3




1x

1/2" x 3/8" OD x #8 Nylon Spacer



1x

1/4" x 3/8" OD x #8 Nylon Spacer




1x


1/8" x 3/8" OD x #8 Nylon Spacer

INK-CREDIBLE TIP

The three spacers between the c-channel and the pink screw is a form of bracing called **box bracing**! Box bracing strengthens the c-channel and prevents it from bending inwards.




4




1x
Thin Nylock Nut

OCTO-MAZING TRICK

The two best ways to **tighten a nylock nut** are using a **wrench** with a thick-handled screwdriver for better grip or a **nut driver** with a screwdriver. Nut drivers are generally easier but too big for tight space, where a wrench works better.




5




1x

#8-32 x 1-1/8" Star Drive Screw




6




1x

1x2x1x9 Aluminum C-Channel




7




1x

1/2" x 3/8" OD x #8 Nylon Spacer




1x

1/4" x 3/8" OD x #8 Nylon Spacer



1x

1/8" x 3/8" OD x #8 Nylon Spacer




INK-DISPENSIBLE ADVICE


If you don't have the exact spacers, you can **combine smaller ones** to match the needed size—for example, two 1/4" spacers make a 1/2" spacer!




8



1x
Thin Nylock Nut



9




1x

1x2x13 Aluminum C-Channel




1x

#8-32 x 1-1/8" Star Drive Screw




10




1x

1/2" x 3/8" OD x #8 Nylon Spacer




1x

1/4" x 3/8" OD x #8 Nylon Spacer




1x


1/8" x 3/8" OD x #8 Nylon Spacer




11



1x
Thin Nylock Nut




12




1x

#8-32 x 1-1/8" Star Drive Screw




13




1x

1/2" x 3/8" OD x #8 Nylon Spacer




1x

1/4" x 3/8" OD x #8 Nylon Spacer




1x


1/8" x 3/8" OD x #8 Nylon Spacer



14



1x
Thin Nylock Nut







OCT-NIFICIANT INSIGHT

Make sure the **bracing is strong** and aligned properly—building on a weak or uneven structure can cause **issues** later.




CHECKPOINT #1

007




15




1x

1x5x1x5 Aluminum C-Channel




2x


#8-32 x 1/4" Star Drive Screw




16



2x
Thin Nylock Nut




17




1x

1x5x1x5 Aluminum C-Channel




2x


#8-32 x 1/4" Star Drive Screw




18



2x
Thin Nylock Nut




19




1x


#8-32 x 1-1/8" Star Drive Screw




20



1x
Keps Nut




21




1x

3/8" x 3/8" OD x #8 Nylon Spacer




1x

1/8" x 3/8" OD x #8 Nylon Spacer




1x

1/16" x 3/8" OD x #8 Nylon Spacer




22




1x


1x2x10 Aluminum C-Channel




23



1x
Thin Nylock Nut



1x
Flat Bearing




INK-STANT ADVICE

This is our first **screw joint**! A screw joint is a connection where a screw serves as a **pivot**, allowing parts to rotate. In VEX, it typically includes a screw, kepinut, spacers, and a nylock nut. The **nylock nut** should be **slightly loosened** to let the c-channel pivot freely.




24




1x


#8-32 x 1-1/8" Star Drive Screw




25




1x
Keps Nut







1x
3/8" x 3/8" OD x #8 Nylon Spacer




1x
1/8" x 3/8" OD x #8 Nylon Spacer




1x
1/16" x 3/8" OD x #8 Nylon Spacer




27



1x
Thin Nylock Nut



1x
Flat Bearing






OCTO-CREDIBLE HACK

It's a tight fit, but doable! Follow step 23, then on the second screw, tighten the kep nut halfway, add spacers one at a time, adjust the kep nut after each spacer, and fully tighten it after all spacers are in place!




CHECKPOINT #2

008




28




1x


#8-32 x 1-1/8" Star Drive Screw




29



1x
Keps Nut




30




1x

3/8" x 3/8" OD x #8 Nylon Spacer




1x

1/8" x 3/8" OD x #8 Nylon Spacer



1x

1/16" x 3/8" OD x #8 Nylon Spacer




INK-SPIRING IDEA

If needed, **loosen nearby parts** for better access to your current step, like adjusting a c-channel to add spacers, then **shift everything back** once you're done.




31




1x


1x2x1x6 Aluminum C-Channel




32




1x
Thin Nylock Nut



1x
Flat Bearing




33




1x


#8-32 x 1-1/8" Star Drive Screw




34




1x
Keps Nut




35




1x
3/8" x 3/8" OD x #8 Nylon Spacer




1x
1/8" x 3/8" OD x #8 Nylon Spacer




1x
1/16" x 3/8" OD x #8 Nylon Spacer




36



1x
Thin Nylock Nut






1x
Flat Bearing




CHECKPOINT #3

009




37




1x


#8-32 x 5/8" Star Drive Screw




38




1x
Keps Nut







1x
1x1x4 Aluminum Angle




40



1x
Thin Nylock Nut



1x
Flat Bearing




TENTACULAR SIGHT


The part you just built is the **lever** that **locks** the clamp! When the piston activates, the lever locks at an angle, making it **difficult to unlock**.




41




1x
Thin Nylock Nut



1x
#8-32 x 3/8" Star Drive Screw




42




1x


#8-32 x 5/8" Star Drive Screw




43




1x
Keps Nut




44




1x
1x1x4 Aluminum Angle




45




1x
Thin Nylock Nut




1x
Flat Bearing




46



1x
Thin Nylock Nut






1x
#8-32 x 3/8" Star Drive Screw




CHECKPOINT #4

010




47




1x


#8-32 x 3/8" Star Drive Screw




48



1x
Thin Nylock Nut




49




1x


#8-32 x 3/8" Star Drive Screw




50



1x
Thin Nylock Nut




51




1x


#8-32 x 5/8" Star Drive Screw




52




1x
Thin Nylock Nut






1x
90 Degree Large Flat Gusset




54




1x


#8-32 x 5/8" Star Drive Screw



55



1x
Thin Nylock Nut




OCT-SOME VIEW


For more **stability**, consider adding **extra screws** onto the gusset and secure it with a nylock at the end!




56



1x
90 Degree Large Flat Gusset




57




1x


#8-32 x 1-1/8" Star Drive Screw




58




1x
1/8" x 3/8" OD x #8 Nylon Spacer



1x
1/32" x 3/8" OD x #8 Nylon Spacer




59




1x

1/8" x 3/8" OD x #8 Nylon Spacer




1x

1/2" x 3/8" OD x #8 Nylon Spacer



1x

Cylinder Mount




EIGHT-POINT ADVICE




For the **new pneumatic piston** with threaded ends that fit a shaft collar, use a 1/4" spacer + 1/8" spacer, then a shaft collar, followed by a 1/4" spacer again. This method will be shown in the **video**, while the current page method is for **older pistons**.


60




1x
Thin Nylock Nut



61




1x
Hex Nut





1x
75mm Stroke Pneumatic Cylinder



TENTACLE-TASTIC TIP

For **extra security**, you can add another hex nut on the outside of the cylinder mount. If you don't have a wrench, use **pliers** to tighten it!



VIDEO TUTORIAL

011

For a more in-depth walkthrough, simply click the video link below!

[youtube link](#)



THANK YOU!